




Machinery | Spares | Consumables
(Specialist suppliers to Tool Hire & Garden Machinery Dealers)


GP43CBCAV Parts List





Item	Part No.	Description
1	GP03010040025	Bolt
2	GP70030030837	Muffler Cover
3	GP70030030834	Housing
4	GP03130010013	Spark Plug
5	GP02020160191	Baffle Of Cylinder Top
6	GP03010010062	Screw M5x20
7	GP70070130003	Cylinder
8	GP02070010021	Gasket,Cylinder
9	GP02020020009	Ring,Piston
10	GP02010020015	Piston
11	GP03090020009	Needle Bearing
12	GP02020150001	Washer,Thrust
13	GP02020010011	Pin,Piston 10 X 30.5
14	GP02020030014	Ring, Snap
15	GP03070010001	Woodruff Key3x5x13
16	GP03060010004	Pin B4x10
17	GP03090010037	Bearing 6202/P53
18	GP70070050005	Front Crankcase
19	GP03100010024	Oil Seal 15X30x7
20	GP02020160737	Washer 5
21	GP03050010008	Washer 5
22	GP03010010071	Screw M5x35
23	GP02050030003	Rotor
24	GP03030010017	Nut M8x1.25
25	GP03040050048	Washer
26	GP02050160006	Clutch Assy
27	GP03040050043	Wave Washer
28	GP02020130003	Clutch Bolt
29	GP70070030041	Flywheel Cover
30	GP03040020018	Washer
31	GP02050120002	Fuel Filter Comp
32	GP02050050137	Wire, Lead
33	GP61330010010	Fuel Pipe
34	GP02110020026	Cap,Fuel Tank
35	GP70050030167	Fuel Tank
36	GP70030030835	Bracket,Fuel Tank
37	GP03020020012	Screw Assy M5x20

Item	Part No.	Description
38	GP02080030016	Rubber Plug,Lead Wire
39	GP02020160265	Plate, Insulator
40	GP02070010079	Gasket,Insulator
41	GP70030020033	Insulator
42	GP03020020053	Screw Assy M5x12
43	GP03030070015	Nut
44	GP02020160426	Adjusting Screw
45	GP03020020034	Screw Assy M5x25
46	GP02020160250	Gasket,Carburetor
47	GP70030040044	Knob,Choke
48	GP02050020033	Carburetor Comp
49	GP02070010055	Gasket,Carburetor
50	GP61330010011	Fuel Pipe
51	GP02020040036	Clip , Pipe
52	GP61330010012	Fuel Pipe
53	GP70030040222	Base, Cleaner
54	GP02050020127	Primer Pump Assy
55	GP02090010014	Air Filter Element
56	GP03020020031	Screw Assy M5x60
57	GP70030040071	Cover, Cleaner
58	GP03020020029	Screw M4x16
59	GP02110010006	Knob,Cover
60	GP02020120068	Crank Shaft Assy
61	GP02070010111	Gasket,Crankcase
62	GP70070050006	Rear Crankcase
63	GP03100010025	Oil Seal 12X28x7
64	GP02050100006	Starter Pulley Comp
65	GP02050070093	Starter Comp
66	GP03020020027	Screw Assy M5x16
67	GP02070010137	Gasket,Muffler
68	GP02050010080	Muffler Assy
69	GP03040020016	Washer 6
70	GP03050010013	Washer 6
71	GP03010010040	Screw M6x55
72	GP02050030220	Ignition Coil Comp
73	GP02050010007	Muffler Cover



Item	Part No.	Description
1	GP61270030058	Gear Case Ass'y
2	GP03120020003	Stop Ring(Φ26)
3	GP03120010002	Stop Ring(Φ10)
4	GP03090010020	Bearing(6000-2Rs/P5)
5	GP02020090071	Pinion
6	GP03010110078	Screw(M5×12)
7	GP03040020017	Washer
8	GP03010030004	Screw(M8×12)
9	GP70070010010	Gear Case
10	GP03020020025	Screw(M5×12)
11	GP02020160081	Safety Guard
12	GP03090010013	Bearing(6002-2Rs/P5)
13	GP02020090022	Gear
14	GP02020090029	Gear Shaft
15	GP03090010012	Stop Ring (Φ32)
16	GP03100010004	Oil Seal
17	GP03120020004	Stop Ring
18	GP02040030017	Bushing
19	GP02020100017	Holder A
20	GP02020100007	Holder B
21	GP02080020007	Rubber Cover
22	GP02040010003	Oil-Bearing
23	GP02020060019	Drive Shaft
24	GP02010010060	Pipe
25	GP70030030836	Snap Ring Set
26	GP02020040069	Clamp
27	GP03010010022	Screw
28	GP02080020136	Down Rubber Cover
29	GP02080020135	Up Rubber Cover
30	GP70030030833	Pipe Cover
31	GP61270020191	Clutch Drum Comp.
32	GP02020050026	Stop Ring
33	GP03120020004	Needle Bearing
34	GP03090010012	Stop Ring
35	GP03120010005	Clutch Comp.
36	GP70070070225	Screw
37	GP03010010058	Rubbler Handle
38	GP02080020102	Handle
39	GP02010030047	Screw

Item	Part No.	Description
40	GP70030180211	Screw
41	GP70020060017	Handle Top Holder
42	GP70020060018	Handle Below Holder
43	GP02020160712	Bracket
44	GP61270070084	Safety Guard Assy
45	GP70030030786	Safety Guard
46	GP70030180314	Blade Protecting Bush
47	GP03010040025	Screw
48	GP02020070102	Blade
49	GP03010050008	Bolt
50	GP03010040036	Screw
51	GP70030070003	Knob
52	GP02020110044	Sping
53	GP2050050205	Stop Switch
54	GP70030070092	Throttle Lever
55	GP70030070051	Spring
56	GP02020110028	Right Control Box
57	GP70030070165	Screw
58	GP03010040038	Screw
59	GP03010010064	Throttle Cable
60	GP02050040175	Nut
61	GP03030010004	Pipe
62	GP61350020004	Stop Wire
63	GP02050050168	Safety Lever
64	GP70030070192	Spring
65	GP02020110029	Left Control Box
66	GP70030070218	Nut
67	GP03030060008	Harness
68	GP02050060118	Screw
69	GP03010040025	Blade
70	GP02060040165	Screw
71	GP03010010056	Screw
72	GP02050220026	Nylon Cutter Head
73	GP02020160306	Washer
74	GP03040050013	Bolt
75	GP03010110116	Bolt
76	GP02020160736	Connection Block
77	GP02080010052	Joint
78	GP70030160158	Clip